



2149 Cascade Ave., Ste 106A-32, Hood River, OR 97031 Voice: 316.558.8643  
Email: [support@crmojo.com](mailto:support@crmojo.com) Home Page: [www.crmojo.com](http://www.crmojo.com)

## Tail Gate Installation

### Tools required:

- Bar tack or equivalent sewing machine with #69 nylon thread
- Marking pencil
- Insertion tool or fid
- Tape measure

### Materials required:

- Tail Gate
- 5.0" 500lb spectra line

### Installation:

- Set the canopy's deployment brakes. If more than one brake setting is available, choose the deepest one you will use.
- Locate the center left C-line
- Mark the center left C-line 1.5" below the point where trailing edge intersects the C-line.
- Insert 500 lb spectra into C-line creating 3/16" "cat's-eye".
- Bar tack spectra loop into place as shown in Figure A.
- Install Tail Gate into spectra loop.

